

Part Number	KW Rating	Item Description	Special Price
<b>Standard DOL Range IP65</b>			
DOLS5.5230	5.5	LOVATO L-STARTER 5.5KW DOL 230V	£25.00
DOLS5.5400	5.5	LOVATO L-STARTER 5.5KW DOL 400V	£25.00
DOLS7.5230	7.5	LOVATO L-STARTER 7.5KW DOL 230V	£29.00
DOLS7.5400	7.5	LOVATO L-STARTER 7.5KW DOL 400V	£29.00
DOLS11230	11	LOVATO L-STARTER 11KW DOL 230V	£38.00
DOLS11400	11	LOVATO L-STARTER 11KW DOL 400V	£38.00
<b>Standard DOL Range With Isolator IP65</b>			
DOLSW5.5230	5.5	LOVATO L-STARTER 5.5KW DOL 230V + ISOL	£75.00
DOLSW5.5400	5.5	LOVATO L-STARTER 5.5KW DOL 400V + ISOL	£75.00
DOLSW7.5230	7.5	LOVATO L-STARTER 7.5KW DOL 230V + ISOL	£77.50
DOLSW7.5400	7.5	LOVATO L-STARTER 7.5KW DOL 400V + ISOL	£77.50
DOLSW11230	11	LOVATO L-STARTER 11KW DOL 230V + ISOL	£80.00
DOLSW11400	11	LOVATO L-STARTER 11KW DOL 400V + ISOL	£80.00
<b>Reversing DOL Range IP40</b>			
DOLR5.5230	5.5	LOVATO L-STARTER 5.5KW REVERSER 230V	£74.00
DOLR5.5400	5.5	LOVATO L-STARTER 5.5KW REVERSER 400V	£74.00
DOLR7.5230	7.5	LOVATO L-STARTER 7.5KW REVERSER 230V	£78.00
DOLR7.5400	7.5	LOVATO L-STARTER 7.5KW REVERSER 400V	£78.00
DOLR11230	11	LOVATO L-STARTER 11KW REVERSER 230V	£110.00
DOLR11400	11	LOVATO L-STARTER 11KW REVERSER 400V	£110.00
<b>Star-Delta Starter Range - (Overload needs to be selected at 0.58 x Motor FLC) IP65</b>			
YD11230	11	LOVATO L-STARTER 11KW STAR-DELTA 230V	£154.00
YD11400	11	LOVATO L-STARTER 11KW STAR-DELTA 400V	£154.00
YD15230	15	LOVATO L-STARTER 15KW STAR-DELTA 230V	£178.00
YD15400	15	LOVATO L-STARTER 15KW STAR-DELTA 400V	£178.00
YD22230	22	LOVATO L-STARTER 22KW STAR-DELTA 230V	£200.00
YD22400	22	LOVATO L-STARTER 22KW STAR-DELTA 400V	£200.00
YD30230	30	LOVATO L-STARTER 30KW STAR-DELTA 230V	£270.00
YD30400	30	LOVATO L-STARTER 30KW STAR-DELTA 400V	£270.00
<b>Star-Delta Starter Range &amp; Isolator - (Overload needs to be selected at 0.58 x Motor FLC) IP65</b>			
YD15SW230	15	LOVATO L-STARTER 15KW STAR-DELTA 230V + ISOL	£199.00
YD15SW400	15	LOVATO L-STARTER 15KW STAR-DELTA 400V + ISOL	£199.00
YD22SW230	22	LOVATO L-STARTER 22KW STAR-DELTA 230V + ISOL	£275.00
YD22SW400	22	LOVATO L-STARTER 22KW STAR-DELTA 400V + ISOL	£275.00
YD30SW230	30	LOVATO L-STARTER 30KW STAR-DELTA 230V + ISOL	£375.00
YD30SW400	30	LOVATO L-STARTER 30KW STAR-DELTA 400V + ISOL	£375.00
<b>Don't forget to pick your Overload from the table below to go with your Starter.</b>			
<b>Use RF38 for the Standard &amp; Reversing DOL : For Star-Delta starters, select overload relay at 0.58 x Motor FLC</b>			
RF380100	0.6-1.0	Thermal overload to suit DOLS/DOLSW/DOLR/YD/YDSW	£16.50
RF380160	1.0-1.6	Thermal overload to suit DOLS/DOLSW/DOLR/YD/YDSW	£16.50
RF380250	1.6-2.5	Thermal overload to suit DOLS/DOLSW/DOLR/YD/YDSW	£16.50
RF380400	2.5-4.0	Thermal overload to suit DOLS/DOLSW/DOLR/YD/YDSW	£16.50
RF380650	4.0-6.5	Thermal overload to suit DOLS/DOLSW/DOLR/YD/YDSW	£16.50
RF381000	6.3-10.0	Thermal overload to suit DOLS/DOLSW/DOLR/YD/YDSW	£16.50
RF381400	9.0-14.0	Thermal overload to suit DOLS/DOLSW/DOLR/YD/YDSW	£16.50
RF381800	13.0-18.0	Thermal overload to suit DOLS/DOLSW/DOLR/YD/YDSW	£19.00
RF382300	17.0-23.0	Thermal overload to suit DOLS/DOLSW/DOLR/YD/YDSW	£19.00
RF382500	20.0-25.0	Thermal overload to suit DOLS/DOLSW/DOLR/YD/YDSW	£19.00
RF383200	24.0-32.0	Thermal overload to suit DOLS/DOLSW/DOLR/YD/YDSW	£30.00